

DJ CONSOLE 4-Mx

How to open the console
Required tools: Phillips screwdriver

- 1) Unscrew the screws shown on the pictures




To do on both sides:



2) Take off the bottom plate:





Now you can check the jog wheel connector.

If you want to take off the defective jog wheel you have to disconnect the connector and unscrew the screws (circled in red) shown on the picture

